Locating Frame for Brush & Abrasive Pads

BGD 526-J-115

Product Description

Locating Frame for Brushes and Abrasive Pads

For use with the following abrasion heads for BGD 526 Wet Abrasion Scrub Testers:

- Abrasion Heads for DIN 53778, model BGD 1179 (BGD 526/Z-006)
- Abrasion Heads for ISO 11998, model BGD 1185 (BGD 526/Z-009)
- Abrasion Heads for ASTM D 2486, model BGD 1186 (BGD 526/Z-010)



These locating frames are required when, in addition to abrasion heads fitted with sponges—models BGD 1187, BGD 1188 and BGD 1189—you also wish to use abrasion heads with brushes or abrasive pads. The respective abrasion heads have different dimensions, and the locating frames ensure correct positioning in the abrader holders.

Locating Frame for Brush & Abrasive Pads

BGD 526-J-115

Main Technical Parameters

Quantity: One piece. Please note that two pieces are required—one for each of the two abrader holders.

Ordering information: BGD 526-J-115 — Locating Frame for Brushes and Abrasive Pads

Disclaimer

The information given in this sheet is not intended to be exhaustive and any person using the product for any purpose other than that specifically recommended in this sheet without first obtaining written confirmation from us as to the suitability of the product for the intended purpose does so at his own risk. Whilst we endeavour to ensure that all advice we give about the product (whether in this sheet or otherwise) is correct we have no control over either the quality or condition of the product or the many factors affecting the use and application of the product. Therefore, unless we specifically agree in writing to do so, we do not accept any liability whatsoever or howsoever arising for the performance of the product or for any loss or damage (other than death or personal injury resulting from our negligence) arising out of the use of the product. The information contained in this sheet is liable to modification from time to time in the light of experience and our policy of continuous product development